

Indu-Sol GmbH – Specialist in Industrial Networks

PROmesh P9+ User Manual



Layer-2-Managed Industrial Ethernet-Switch











CAN DeviceNet SafetyBUS p ASI ASI CEMC WIRELESS

Indu-Sol GmbH Blumenstraße 3 D-042626 Schmölln Phone: +49 (0)34491 / 580 0 Fax: +49 (0)34491 / 580-499 Email: info@indu-sol.com

Web: https://www.indu-sol.com

Our **technical support** team is available at +49 (0)34491 / 58 18 14, weekdays between 7:30 – 16:30 (CET). You can also email us at: support@indu-sol.com

Is your plant standing still? You can reach our emergency service around the clock at: +49 (0)34491 / 580 0.



Revision overview

Date	Revision	Change(s)
30/06/2022	0	First version
16/08/2022	1	Switch Technology
30/11/2022	2	VLAN Menü
16/02/2023	2.1	Cover

© Copyright 2022 Indu-Sol GmbH

We reserve the right to amend this document without notice. We continuously work on further developing our products. We reserve the right to make changes to the scope of supply in terms of form, features, and technology. No claims can be derived from the specifications, figures, or descriptions in this documentation. Any kind of reproduction, subsequent editing, or translation of this document, as well as excerpts from it, requires the written consent of Indu-Sol GmbH. All rights under copyright law are expressly reserved for Indu-Sol GmbH.

WARNING

Commissioning and operation of this device must only be performed by qualified personnel. Qualified personnel within the meaning of the safety notices in this manual are persons authorised to commission, ground, and mark devices, systems, and circuits in accordance with safety engineering standards.

Improper use or configuration of the *PROmesh P9+* in the network may cause severe physical injury as well as property and material damage, also due to uncontrolled machine movements.



Table of contents

Revisio	n overview	3
Table of	f contents	4
1	General information	6
1.1	Overview of the PROmesh P9+ – function scope	6
1.2	Scope of supply	7
1.3	Safety notices	7
2	Connections and status indicators on the device	8
2.1	Device connections	8
2.2	Installation	9
2.3	Mounting	9
2.4	Connection of power supply and error relay	10
2.5	LED displays	12
2.6	Reset button	12
2.7	Network integration & commissioning	13
2.7.1	Data ports	13
2.7.2	Media selection & connection	13
2.7.3	Wiring	13
2.8	Network topologies & redundancy	14
2.8.1	Network topologies	14
2.8.2	Ring structure	14
3	Web application	16
3.1	Preparations	16
3.2	System login	17
3.3	Web interface	17
3.4	Start	18
3.5	System information	20
3.6	Diagnosis	20
3.6.1	Line diagnostics	20
3.6.2	Leakage current	22
3.6.3	Network statistics	22
3.6.4	Neighbourhood detection (LLDP)	24
3.6.5	Port mirroring	24
3.6.6	Alarm trigger	25
3.6.7	Messages	27
3.7	PROFINET	28



3.8	Switching	28
3.8.1	Port configuration	28
3.8.2	Quality of service	30
3.8.3	VLAN	31
3.8.4	Bandwidth control	32
3.8.5	Link aggregation	33
3.9	Redundancy	34
3.9.1	MRP	34
3.9.2	RSTP	35
3.9.3	MSTP	38
3.10	System configuration	39
3.10.1	Device information	39
3.10.2	IP configuration	40
3.10.3	Password	41
3.10.4	Time setting	41
3.10.5	SNMP	42
3.10.6	Access time	43
3.10.7	Backup	44
3.10.8	Recovery	44
3.10.9	Firmware update	44
3.10.10	Factory settings	46
3.10.11	Reboot	46
3.11	Support	46
3.12	Troubleshooting advice	46
4	Technical specifications	48



1 General information

Please read this document thoroughly from start to finish before you begin installing the device and putting the device into operation.

1.1 Overview of the *PROmesh P9+* – function scope

The *PROmesh P9+* is an industrial Ethernet switch with management and PROFINET functions that can be configured easily and conveniently via a web application. It supports the effective setup of all network topologies, such as bus, star, and ring structure in your plant, with its comprehensive functions with Store & Forward technology.

Features:

- Web application for configuration
- Anti-reverse supply 12-48V DC, redundant operation possible
- Line diagnostics
- Leakage current monitoring
- Port statistics (network load in ms, errors, discards)
- Alarm management
- 9 x 10/100/1000 Mbit/s RJ45
- Switch technology: Store & Forward
- MAC address table: 16K (16384 addresses)
- PROFINET Conformance Class B
- PROFINET Netload Class III
- Quality of Service (QoS) with eight priority queues
- Prioritisation by class of service (COS), type of service (TOS), or port priority
- Limitation of incoming and outgoing packets
- Port mirroring (Rx/Rx and Tx packets)
- Port-based VLAN with 4096 possible VLAN IDs
- Simple Network Time Protocol (SNTP) client and NTP server
- Simple Mail Transfer Protocol (SMTP)
- Internet Group Management Protocol Snooping (IGMP Snooping)
- Dynamic Host Configuration Protocol (DHCP) client function
- Simple Network Management Protocol (SNMP), v1, v2c, v3
- Update, save, and backup the system configuration via web interface, TFTP, and memory card



1.2 Scope of supply

The scope of supply comprises the following individual parts:

- PROmesh P9+
- 7-pin pluggable terminal block, 2.5 mm² (power supply and alarm contact)
- User quick start guide (hardcopy)
- SD card, for backup and update

Check that the content of your delivery is complete before commissioning. In case of questions, contact our technical support team immediately before commissioning.



Insert the external memory card into the corresponding slot on the back of the unit before using the device for the first time (see Figure 1).

1.3 Safety notices



Check that it is in perfect condition externally before commissioning of the device. If any damage is suspected, return the PROmesh P9+ to your supplier immediately and do not operate the device. Our technical support team will be happy to answer any questions you may have.



The **PROmesh P9+** was developed for use in PROFINET applications in accordance with conformance class B. Also note the selection of the data lines used in accordance with the standard to fully support the PROFINET standards.



Always observe the technical specification of the device to ensure safe and optimum use. The device is designed for IP30 protected environments. Take appropriate measures in case of deviating operating environment to ensure proper operation of the device.



Do not open the housing under any circumstances. No parts that require servicing have been installed. Unauthorised opening of the housing will void any warranty claims.



2 Connections and status indicators on the device



Device connections

Figure 1: Device connections



2.2 Installation

The PROmesh P9+ is designed for individual use in control cabinets of various types and can be mounted on a standard 35 mm DIN top-hat rail.

Only use the existing top-hat rail fastening for mounting the device or, if necessary, purchase appropriate spare parts to ensure sufficient electrical contact and the mechanical load capacity of the device.

2.3 Mounting

The *PROmesh P9+* is mounted vertically in the control cabinet on a 35 mm DIN top-hat rail in accordance with DIN EN 60715.



Figure 2: Side view with connection terminal on the right

0

The following distances to other assemblies must be observed for correct mounting:

- To the left and right: 20 mm
- Up and down: 50 mm

Assembly and disassembly of the device are displayed in Figure 3.





Figure 3: Mounting and dismounting on the top-hat rail

Do not mount the *PROmesh P9+* switches directly adjacent to any devices that generate strong electromagnetic interference fields, such as transformers, contactors, frequency converters, etc.



Do not mount the *PROmesh P9+* switches directly adjacent to any heat-generating devices and protect the switch from direct sunlight to avoid unwanted heating. Protect the PROmesh P9+ from any additional heat radiation and observe the permitted storage and operating temperature range.

2.4 Connection of power supply and error relay

Operate your *PROmesh P9+* with a nominal voltage of DC 12 V to 48 V. Connect the redundant power supply VDC1 and VDC2 to the correspondingly marked connection terminals of the supplied 7-pin terminal block adapter (VDC1, GND as well as VDC2, GND) to ensure your system availability. The power supply shall comply with UL60950-1/UL62368-1, Class 2 (NEC), limited energy source (UL61010-1).

The 7-pin 2.5 mm² connector terminal block on the top of the device is assigned as follows:



Figure 4:Connector terminal block assignment



The listed labels are also included on the connector terminal block supplied.

There is a potential-free error relay contact (NC contact) at the OUT terminals inside the unit. The relay serves as an alarm receiver. It can be linked to various alarm triggers in the software. The relay contact then opens, for example, in case of a power outage or a change in the status of the port depending on the configuration.



2.5 LED displays

There are four diagnostic LEDs on the front panel of the switch.

Each of the 9 data ports also has a status LED.

The LEDs display the most important diagnostic information about the device and connection status of the PROmesh P9+ in your PROFINET network (see Table 1).

LED	Status	Meaning
VDC1	Green	Voltage at connection sufficient
VDCT	Off	Voltage at connection insufficient
	Green	Voltage at connection sufficient
VDC2	Off	Voltage at connection insufficient
Status	Green	Active PROFINET connection to the controller
Status	Yellow	No PROFINET connection to the controller
Error	Red	Configured alarm active
Endi	Off	No configured alarm active
	Off	No link
LED ports 1-9 (green)	Flashing	Link + data exchange (flashing speed reflects link speed)
	On	Link

Table 1: LED functions

2.6 Reset button

The reset button can be used if the PROmesh P9+ experiences any unexpected abnormalities that render it inaccessible. It can either restart the PROmesh P9+ or reset to its factory settings. This requires the following procedure:

- Restarting the device: Push the reset button for 1 second
- Reset to factory settings: Push the reset button until all LEDs go out (approx. 10s)



2.7 Network integration & commissioning

2.7.1 Data ports

The *PROmesh P9+* is equipped with 9 data ports that allow data transmission at up to 1.0 Gbit/s in compliance with PROFINET standard 2.4. The actual data rate is negotiated by the device using auto-negotiation.

2.7.2 Media selection & connection

The PROmesh P9+ has nine data ports for connecting RJ-45 copper cables.

Observe the applicable standards and fixed connections in the connector application when designing, selecting, assigning, and assembling your data cable in order to ensure the longest possible cable length and cascading of network segments in accordance with your media type (copper, optical fibre, etc.).

2.7.3 Wiring



Connect your PROmesh P9+ via the existing RJ-45 data ports using twisted pair cables of category 5 (Cat 5) or higher with a maximum cable length of up to 100 m. We recommend the PROFINET RJ45 connectors from Indu-Sol to improve the shielding.



2.8 Network topologies & redundancy

The devices of the *PROmesh* product family can be used in redundant networks, such as meshed networks or rings, via different protocols in addition to being used in star-shaped switched Ethernet networks.

2.8.1 Network topologies

Classical Ethernet star structures (see Figure 5) can be linked to the *PROmesh P9+* switches without additional configuration. The devices are ready for use immediately.



Figure 5: **PROmesh P9+** in a star network

2.8.2 Ring structure

The **PROmesh P9+** supports the IEC 62439 standard, thereby enabling deterministic reconfiguration of information forwarding in simple redundancy (ring topologies, see Figure 6). This enables reconfiguration times of up to 200 ms, depending on the size of your system.





Figure 6: *PROmesh P9+* in a ring-shaped network



3 Web application

The *PROmesh P9*+ switches are equipped with a modern web interface that may be configured comfortably from any web browser.

3.1 Preparations

Install the *PROmesh P9*+ switch on the network before using web management and ensure that the PC designated to configure the switches can access the switch through the web browser. The PROmesh P9+ and the client PC to be connected must be in the same IP address range and IP subnet. You must assign an PROmesh P9+ IP address at first use for this.

The following IP address, subnet mask, administrator username, and administrator password are set when the device is shipped from the factory:

- IP address: 0.0.0.0
- Subnet mask: 0.0.0.0
- Gateway: **0.0.0.0**
- Username: admin
- Password: admin

Make sure to change the factory-set password when logging in for the first time. You are responsible for documenting this password and protecting it from unauthorised access.

You can easily set your intended user addresses with the **Indu-Sol ServiceTool**. This is part of the scope of delivery or can be downloaded for free via the following link: https://sdx.indu-sol.com/s/CtYtsHNW73Z3KCa

Our software is updated regularly. Please ensure that you have the latest version.

Establish a network connection from your computer to a port of the switch and scan the system with the search setting *PROFINET device* after installing and opening the software. You can then make the appropriate entries in the input mask and save them.

The corresponding address settings are then made automatically this way if you include the switch in a PROFINET system in the hardware configuration of the controller.

A user access with lower authorizations and adapted menu navigation is available as an alternative to the administrator access. The user has no access to the Switching, PROFINET and redundancy functions or their sub-items. The submenus for system configuration are also restricted. The access data for this are:

- Username: user
- Password: user



3.2 System login

- 1. Launch a web browser on your computer.
- 2. Enter the IP address of the *PROmesh P9+* switch you are using into the address line of the web browser and confirm your entry with the *Enter* key.
- 3. The login mask of the device now appears on the screen.

	🇊 PROmesh P9+		Name of Station - Device Location - B Address - Help
	Login		4
→) Login * Support & Contact		Usemame Password Login	
🌐 Language 🛛 🔨	© 2022 Indu-Sol GmbH		

Figure 7: Login mask

- 4. Select the desired menu language (DE / EN). You can change this at any time, in any menu of the web interface.
- 5. Then enter the username and password.
- 6. Pressing the Enter key or clicking Login will take you to the switch web interface.

3.3 Web interface

The following symbols are used in the web interface for a simple status display of the individual ports:



No error: The communication works without any errors.



Warning: At least one communication fault (discards, error) has occurred on the corresponding port, which has not yet led to a failure. The cause of these events should be located and corrected.



Error: A critical fault has occurred on the corresponding port, resulting in a communication interruption. Urgent action is needed to correct the disruption.





There is no communication at the respective port. Either no device is connected (potentially also at line interruption) or no telegram traffic can be detected (serious fault in the network) or the devices no longer communicate.

3.4 Start

Successful login will lead to the main overview with the information bar, where the device name, the installation location, and the IP address are displayed. The current user is displayed under the logout button at the right end of the bar. You can log out by pushing the button. The help button displays notes and explanations for the individual pages.

The port statistics provide an overall view of the state of the existing ports since the switch was started or reset (history) and within the last minute (current). You can choose between two views. In the Overview view:

- Current partners
- Transmission speed
- Diagnostic messages

are displayed. In the Details view, the parameters of the overview and:

- Mains load per s
- Discards
- Errors
- Line quality value

are displayed.

The number of messages that have occurred is displayed in the message window. Clicking on the alarm bell will automatically call up the entries in the message list. The messages as well as the counter status of the ports can be deleted with the corresponding buttons.

The leakage current overview shows the current value between the RJ45 ports and the device's top-hat rail. It is possible to switch between the display of the peak value (peak) and the effective value (RMS) or this. This information makes interference currents visible at an early stage, which can lead to direct communication disturbances.



The top-hat rail must have been grounded properly in order to measure the leakage current correctly.

Selection in the menu bar allows you to call up the individual pages and make settings there. The displayed menu items are subdivided into further subitems.



PROmesh P9+ Message M window Port rt Status witching Time base Last second Overview Details System Config Port 1 (native) Neighbour: Port 2 (satis) Port 5 (nactive) Neighbour: Port 4 (1000 MBH99) Neighbour: v 172.30.152.11 Port 3 (nactive) Port 6 (naithe) Neighbour: Port 7 (sactos) Neighbour: Port 8 (nactive) Port 9 (native) Neighbour: nce last reset: 13 Minutes Leakage eld Current RMS Peak The base Last second * 0 15 mA trum Downlo

Figure 8: Start



3.5 System information

An overview of the enabled or disabled protocols and functions is displayed under this menu item in addition to the device information. You can switch directly to the corresponding protocols and functions in order to make settings there by selecting the respective Edit button.



Figure 9: Status and diagnosis

3.6 Diagnosis

The diagnosis page provides an overview of the status of configured alarm triggers (alarm trigger configured or not) for the individual diagnostic data acquired by the PROmesh P9+. The status for topology determination and port mirroring is also displayed.

3.6.1 Line diagnostics

Line diagnosis is available for ports 1 - 9. The quality of the connected connections is checked cyclically (every second). The line quality can lie between the values 100 and 0%. In this context, 0% corresponds to a defective cable, i.e., no data exchange is possible.



	🗊 PROmesh P9+		Name of Station- RROmesh P9+ Device ±06ation: IP Address: 172/30.162.5 Logout Help
	Diagnosis > Line Diagnostics		μ
Home System Information Diagnosis Line Chaptotics Leakage Current Network Statistics	Physical quality evaluation of connected data lines. Quality Values	^	2 Messages Delete messages Delete counter
Neighbourhood Detection Per Minoring Alex Triggers Michicates Reflectates Refl	100 %	Quality values of Port: 4 Image: Comparison of Port: 4 Im	
🏶 Language 🔨 🔨	@ 2022 Indu-Sol GmbH		

Figure 10: Quality value

Information bar chart

3 values are displayed per bar.

The grey part of each bar shows its maximum value. The lesser coloured part, bordered by a black line, shows the current quality value. The colour-saturated part, which is bordered by a line with 2 arrows, shows the worst quality value of the connection so far. Colouring of the bars is based on this, which is done in accordance with the traffic light colour principle with green-yellow-red:

- Green: The line quality is in order; no measures required.
- Yellow. The defined threshold value of 30% was not reached. The line quality is not sufficient. The connection should be checked at the next maintenance interval.
- Red: No more data exchange can take place. Check the plug contacts and the data line.

A cable designation can be stored for each port in the port configuration menu. This can be displayed with a "mouse-over" (moving the mouse pointer over the port).

Miscellaneous

The threshold value that turns the bar yellow and recommends checking the connection, can be adjusted by the user. It is not recommended to set the threshold value below 30%. The alarms menu can be used to define alarms for the line quality value, which send messages via relay, SNMP, PROFINET, or email when a threshold value is undershot.



3.6.2 Leakage current

Leakage current monitoring (Figure 11) permits permanent recording and evaluation of the sum of all shield currents of the PROFINET lines that are discharged via the device into the equipotential bonding system. The associated spectrum with the respective frequency components is specified for this purpose, in addition to the current value. The PROmesh series offers mechanisms for detecting EMC interference or coupling with this function.

Other functions:

- Download of the frequency spectrum after a threshold value has been exceeded
- Switching the axes between decimal and logarithmic scaling



Figure 11: Leakage current

3.6.3 Network statistics

The port statistics page provides information about the traffic on each port. This information is useful for diagnostic purposes or in case of network problems.

In the main overview of the port statistics, the following information is provided for each port:

- Received data packets
- Data packets sent
- Maximum mains load
- CRC error (destroyed telegrams)
- Discards (telegrams discarded due to too much data)



	🗘 PI	ROmes	h P9+						Name of Station #Romesh P9+ Device Location: IP Address: 172:30.152.5 Lagout
	Image: Product Statistic Endework Statistic Current helfferent ports. Current network statistics for the different ports. Image: Comparison of the different ports.								
😤 Home									
System Information	Curre	ent network	statistics f	for the diffe	erent ports.			An	
M Diagnosis								// •~	2 Messages
Line Diagnostics	Netwo	rk Statistic						^	Delete messages
Network Statistics		in outsto							Delete counter
Neighbourhood Detection		max. Netlo	oad			Pack	cets		
Port Mirroring	Port	/ ms	/s	Errors	Discards	sent	received	Nodes of Cost 4	
Notifications	1	0 %	0 %	0	0	0	0	Neubau / S of Port 4	PROmesh P9+
PROFINET	2	0 %	0 %	0	0	0	0	annun	P1 P2
Switching	3	0%	0 %	0	0	0	0	40 60	
	4	5%	5%	U	U	13,182	96,262	101 20 80 M	
Redundancy	6	0 %	0 %	0	0	0	0	■ =_ 100 = □	PS C
System Configuration	7	0.%	0.%	0	0	0	0	Minimum: 0%	
Support & Contact	8	0 %	0 %	0	0	0	0	Current: 0% Maximum: 5%	
	9	0 %	0 %	0	0	0	0	Maxillani. 570	
	Time since	e last reset: 5 Minut	es						
	Detaile	d Network St	atistic					~	
() Language	@ 2022 Indu-Sol Ombi-	1							

Figure 12: Port statistics

Resetting the values

The upper right part of the web interface contains the "Delete counter" button. The values of the table can be reset with this button.

Detailed port statistics

The size of the individual packets is recorded statistically up to various threshold values in the statistics details (up to 64, 127, 255, 511, 1023, or 1518 bytes).

The packets sent are distinguished as follows:

- Number of unicast packets (packets to one receiver)
- Number of non-unicast packets

The received packets are distinguished between:

- Number of all packets
- Total bytes received
- Number of received fragments

The line *Packets up to bytes* gives information about the number of packets in different sizes. This records the number of packets received up to 63, 127, 255, 511, 1023, or 1518 bytes in size.

In addition, packet collisions are detected and distinguished by:



- Late (a collision that occurs after more than 512 bits)
- Total

. Such collisions and the associated data loss always occur when several subscribers want to send simultaneously on one medium.

3.6.4 Neighbourhood detection (LLDP)

The Link Layer Discovery Protocol (LLDP) is a vendor-independent layer-2 protocol that provides the ability to exchange information (addresses, names, and descriptions) between neighbouring devices. An LLDP agent operates on every device that supports LLDP. This sends information about its own state at periodic intervals and receives information from neighbouring devices.

Since this is done independently, LLDP is also referred to as a one-way protocol.

The following information is compiled and sent by LLDP:

- Port name
- Device name
- IP address
- Device description

MAC table

The forwarding database provides information about which MAC address is connected to which port of the switch.

Settings

The LLDP interval parameter can be used to define the time intervals (in seconds) where the device-specific LLDP telegram is sent to the neighbouring devices. The default setting is 5 seconds.

3.6.5 **Port mirroring**

Port mirroring is a method of simultaneously directing traffic from one port (source) to a second port (destination) in networks for inspection. This means that the received and sent packets of the source port are duplicated to the monitoring port.

Monitoring of the source ports takes place without affecting the traffic of this port. The resulting mirror port can be connected to a LAN analyser or used for diagnosis and debugging.



- Port and port name: All ports are displayed here in order to select a destination port and one or more source ports.
- Destination port: If port mirroring is enabled, select a port on which to mirror the data. The mirrored packets can be forwarded to exactly one destination port.
- Source port: You can select which ports to monitor and forward their packets to the destination
 port here. It is possible to route only sent packets (TX for transmit) to the destination port or to
 monitor both directions, i.e., sent (TX for transmit) and received (RX for receive) packets. You
 can select a maximum of eight source ports on the switch. Check the respective checkbox to
 select a port.

After you have set the respective parameters, click the Apply button to save and apply the settings.

3.6.6 Alarm trigger

The menu item Alarms is used to configure alarm triggers and alarm receivers. Alarms can be created for the following events:

- Changing the status of a port
- Temperature too high or too low
- Failure of a power supply voltage
- MRP protocol event
- Exceeding of a leakage current
- Exceeding the network load on a port
- Incorrect connected neighbour (can only be configured via the configuration software)
- Undercutting of the line quality value
- Voltage value of the 24 V power supply too high or too low

The alarms created can be linked to one or more alarm receivers, these include:

- Error relay
- SNMP traps
- Email addresses
- PROFINET (only configurable via configuration software)

If one of the alarms set up is detected and triggered, the software will forward the event to the corresponding alarm receiver and document the event as a syslog message.



	🍞 PROmesh P9+	Num of Tillade PROheith Pay Device Lovasor IP Address 17,2 56 182 6 Samma Lagott Heldr
	Diagnosis > Alert Triggers	٨
合 Home		
 System Information Diagnosis 	You can change the alert settings here.	2 Messages
Line Diagnostics Leakage Current Network Statistics	Triggers	Delete messages Delete counter
Heighbeundend Detection Perk Minning Aust Tegner Heldinationa I Statuter I Redundancy I Redundancy III System Configuration IIII Support & Cottact	Temperature Power Supply MRP Shield Lower Level 40°C Source VOC1 MRP Shield Upper Level 50°C Voc1 Voc1 MRP Shield Shield V Image: Voc1 Voc1 Voc1 Voc1 Voc1 Lower Voc1 Lower Voc1 Lower Voc1 Lower Voc1 Lower Lower	Current Durity Values Paris Ports, Po
	PROFINET SHMP Boot 192:150.0 Commandy pade Version V2C	Apply Cancel
🌐 Language 🔥 🔨	@ 2022 Indu-Sol OmbH	

Figure 13: Alarm trigger

The configured alarm assignments are displayed in lists with consecutive ID.

- Alarm triggers with assigned receivers
- Alarm receivers with associated triggers

Add and edit alarm triggers

New alarms and messages can be added by clicking on the button with the "+" symbol. If alarms are already present, the user has the option of editing or deleting them using a button. In the upper part of the "Alarm trigger" pop-up, the user can select the different alarms. The associated recipients can be selected in the lower part of the pop-up and linked to the alarm trigger in this way when the alarms are set up and edited, provided that the alarm recipients have already been defined.

Adding and editing alarm recipients

New alarm recipients can be added by clicking on the button with the "+" symbol. The relay is already present as an alarm receiver and cannot be deleted, only linked to alarm triggers. The recipient email, SNMP, and PROFINET can be selected as well. The associated alarm triggers can be linked to the current recipient in the lower part of the pop-up.

• Error notifications are generated by the device and sent to a management station without being requested with Simple Network Management Protocol (SNMP). The device cannot determine whether the manager received the information since the packets are not acknowledged.



- The user can specify an email address and an SMTP (Simple Mail Transfer Protocol) server when using the email function. The device sends an email to the user if there is an alarm. Authentication can be enabled as an option. The required access data must be entered for this purpose.
- Once the switch has been integrated and parametrised in a Profinet network, the "PROFINET" alarm receiver is permanently set in the system and cannot be changed in the device. The alarm triggers for the individual events are enabled in the hardware configuration of the controller. If a trigger occurs, the switch sends an alarm message to the controller. This information can then be processed programme-technically within the PLC.

3.6.7 Messages

The messages help the user view status and error messages of the various functions. The messages are displayed in the overview with date and time, as well as a code, type, description, and reference. Since the log entries are not stored in the device, they are no longer available after a device restart or a power interruption. It is possible to use an external syslog server or the SD card to archive the messages permanently.

Statistics

This tab provides a summary of the individual error codes that have occurred and their frequency.

Settings

- Syslog server: Enable this function to save the messages on a syslog server. Enter the syslog
 server IP address in decimal point notation, select "File" from media type, and save the settings
 using the Apply button. Check if the server is reachable and saves the messages in a file.
- Media type SD card: Ensure that an SD card is inserted to save the messages on the SD card. Then select "SD card" under Media type and save the settings using the Apply button. Please check whether there is enough free memory on the SD card and whether the messages are saved in a file.

Resetting the entries

 The button "Delete entries" removes all entries from the table. The time of deletion of the entries can then be viewed as the first entry with the description "Logfile reset by User!" and reference "logFileReset()".



3.7 PROFINET

The abbreviation Profinet means Process Field Network. It refers to the open Industrial Ethernet standard for automation.

The device is developed as a Profinet IO device for connection of decentralised peripherals to a Profinet controller. The device supports conformance Class B. This page offers the option of making port settings for DCP and downloading the configuration file.

DCP settings:

You can specify for each port whether it supports the discovery and configuration protocol (DCP).
 DCP is used to distribute addresses and names to the individual subscribers in a Profinet IO system.

Additional information

The configuration file stored on this page is used to describe Profinet field devices. The file is written in General Station Description Markup Language (GSDML). The file serves as a basis for planning the configuration of a Profinet IO system. Furthermore, the current state of the device in PROFINET, the PROFINET name assigned as well as its controller (if available) is displayed.

3.8 Switching

This page provides an overview of the enabled and disabled functions in the Switching area. You can see which functions are currently enabled right away. Clicking the Edit button takes you directly to the various pages to make further settings there.

Port configuration

The table provides an overview of the current configuration of the individual ports. The columns Enabled, Autonegotiation, Flow Control, and Designation can also be edited. The page is regularly refreshed and reloaded.



	🗘 PR	Omes	h P9+								Device Location. PROMest PSP address: 172.30 152.6 Loc
860	Sutiching > Port Configuration										
formation	Here yo	u can ch	ange the	settings	of the diffe	rent ports o	f the swit			1	
										//	2 Messages
	Port Cont	Souration									Delete messag
	Forcom	iguration									Delete counte
ation					Auto Negotiati	ion					
nice	Port	Status	Enabled	Enabled	Speed	Duplex	MDI(X)	Flow Control	Descr	ription	
antrol	4				Automatic	Automatic	MDI		Port 1		PROmesh P9+
ion					Automatio	L topolo	LID:		Part 2		
τy.	4				Motomatic	Actionatic	MLA		10112		
nfiguration	3	•	2	2	Automatic	Automatic	MDI		Port 3		ĭ ª∟Ŀ
Contact	4	•	•	S	1000 MBit/s	Ful	MDI		Port 4		
	5			≤	Automatic	Automatic	MDI		Part 5		
	6	0	2	•	Automatic	Autometic	MDI		Port 6		S 20
	7		•	•	Automatic	Automatic	MDI		Port 7		
	8	0	•	•	Automatic	Automatic	MDI		Part 8		
	9		•	•	Automatic	Automatic	MDI		Part 9		
	Port configuratio Reset	n may not be alte	ered with an activ	ve PROFINET cor	nection.					Apply Cancel	

Figure 14: Port configuration

Details on the columns:

- Port: Specifies the port number, also marked on the housing.
- Enabled: The individual ports can be enabled or disabled. This specifies whether a port can be used or not.
- Status: Status signals the current state of the ports:
 - o green: The port is enabled and there is a connection.
 - o grey: The port is inactive or disabled.
- Autonegotiation: If this function is enabled, the transmission speed and duplex mode are configured automatically. The device and the connected remote party negotiate the settings automatically. If autonegotiation is disabled, the settings can be firmly set manually:
 - Speed: The data rate of the ports can be firmly set. A data rate of 10 Mbps or 100 Mbps can be set.
 - Duplex: Duplex mode can be switched between half and full duplex. This setting is thus set firmly for a connection.
- MDI(X): The device can perform autocrossover detection by default. This means that the switch automatically detects whether the subscriber is connected via a crossed or non-crossed cable.
- Flow control: Flow control ensures that if a port is overloaded, the received data packets are ignored, and the connected device is signalled to stop sending.
- Designation: You can give the ports names in this column. The names are displayed throughout the configuration and facilitate the selection of the correct settings as well as diagnosis in the event of a fault. Click the port name to edit the name in the line.



3.8.2 Quality of service

Quality of service (QoS) includes all procedures that influence the data flow in the device. With the assignment to queues with different priorities, certain user data can be treated preferentially. For example, real-time data, control data, audio or video data may be preferred over file transfers.

The switch supports eight different queues that are processed with different priorities. It is possible to use only one of the classification methods listed below or to combine several.



Figure 15: Quality of service

QoS mode and priority scheme

The QoS mode distinguishes between the following settings:

- Port based: You can set a priority for data transmission for each port and the switch will forward the data packets of that port in accordance with your priority.
- Classes based (COS): COS uses a data field present in the VLAN tag with priority information.
 Eight different priority values from best effort (BE,0-low) to network Control (NC,7-high) are specified. Assign the COS priorities to the switch's four queues as needed in your application.
- Type based (TOS): TOS uses a differentiated services code point (DSCP) data field in the IP header of packets that can have up to 64 different priorities. As with COS, you can use these priorities to prioritize real-time control data, Voice over IP (VoIP), or audio data over normal data transfer, for example. Adjust the settings to your requirements.
- QoS mode:
 - Port-based only: Priorities are based only on the priority of the ports.



- Class of service only: Priorities are based solely on the class of service data field of the packets.
- Type of service only: Priorities are based solely on the type of service data field of the packets.
- Class of service first: In this variant, priorities are determined first by COS, then (if necessary) by TOS, and finally by port.
- Type of service first: Here, priorities are determined first by TOS, then (if necessary) by COS, and finally by port.
- Priority scheme:
 - Strict priority scheme: In the strict priority scheme, all packets leave a port until the associated priority queue is empty. Only then are packets sent from the lower priority queues. If packets arrive permanently in the highest priority queue, packets in the lowest priority queue may never be sent. This mode is recommended when there are very high real-time requirements.
 - Weighted order: This approach prevents low-priority packets from never being sent when there are permanent high-priority packets to be sent. There is only a slightly higher latency for the high priority packets. The switch primarily sends high priority packets and also processes all low priority queues in one send cycle.

VLAN

A virtual LAN (VLAN) is a logical group of network subscribers. It allows the isolation of a network part. Any traffic from network subscribers of a VLAN group is transferred only within the VLAN group.

In the VLAN menu, VLAN settings can be made for each individual port. You can define port-specific in which VLAN a port should have its PVID and for which VLANs the port should be untagged or tagged.

- Tagged : Ports that are configured as tagged in a VLAN provide packets with a VLAN tag. Usually switch - switch connections are configured as tagged. A port can be configured as a tagged port in multiple VLANs. This means that VLANs are not restricted to individual switches, but can also be operated across multiple switches.
- Untagged: Ports that are stored as untagged in a VLAN can receive and forward packets of this VLAN ID. A port can be stored as an untagged port in multiple VLANs if the devices connected to this port shall communicate with multiple VLANs.
- PVID: Only one PVID can be assigned to each port. The PVID determines to which switchinternal VLAN group the incoming packet is assigned. The VLAN tag of the packet header is not yet changed by this. Only when the packet leaves the switch via a tagged port is the VLAN tag entered according to the PVID of the incoming port.

Global you can define:



- The management VLAN: The switch itself can be reached via the management VLAN. If the switch is
 parameterized in a PROFINET controller, an EtherNet/IP scanner or another management software,
 then it must be ensured that the management VLAN is located in the same VLAN as the
 scanner/controller/software.
- VLAN can be deactivated/activated: By default, VLAN is disabled. This causes the switch to operate in the Transparent mode. If VLAN is activated then the switch works in the Bridge mode.

	On			Curren	t Status 🗸 Active
VLAN	N Configura	ation			^
					Management VLAN
Port	PVLAN	Tagged VLANs		Untagged VLANs	
1	2		1-2		
2	<u>1</u>		1		
3	2		1-2		
4	5		2-3,5		
5	3		3		
6	<u>1</u>		1		
7	1	2-5	1		
8	<u>1</u>		1		
9	1		1		
	Reset			Apply	Cancel



3.8.4 Bandwidth control

Bandwidth control makes it possible to enforce bandwidth limits on a port. You can set different send and receive rates for each port (incoming/outgoing packets) and apply them to specific packet types.

The tabular overview offers the following settings:

- ID: Specifies the port number, also marked on the housing.
- Packet type: Select a packet type to filter by.
 - o All: The specified limits are observed for all packets transported via the port.
 - o Broadcasts: The set limits apply to all broadcast packets (to all devices in the network).



- Broadcast & multicasts: The set limits apply to all broadcast and multicast packets (to all or multiple devices on the network).
- Broadcast, multicast & unknown unicasts: The limits apply to all broadcast, multicast, and unknown unicast packets (to one subscriber).
- Limit of incoming packets: Select the effective ingress rate of the port. Possible are 128 kbit/s, 256 kbit/s, 512 kbit/s, 1 Mbit/s, 2 bBit/s, 4 Mbit/s, and 8 Mbit/s. "No limit" is defined as the default value.
- Outgoing packet limit: The data rates for outgoing packets refer to all packet types. Select the effective egress rate of the port. Possible are 128 kbit/s, 256 kbit/s, 512 kbit/s, 1 Mbit/s, 2 Mbit/s, 4 Mbit/s and 8 Mbit/s. "No limit" is defined as the default value.

After you have made the desired settings, click "Apply" to save them.

3.8.5 Link aggregation

Using the link aggregation function, several physical connections can be combined into one logical connection. This way, you can transfer greater amounts of data between 2 devices. (If you combine 2 physical connections between 2 PROmesh P9+ by means of link aggregation, then instead of 1 x 1Gbit/s up to 2x 1Gbit/s can be transmitted)

Link aggregation can be static or dynamic.

Static

You can add a new link aggregation group via the "+" button. Then you can:

- Group ID: Each link aggregation group has an ID (1-14)
- Type: Specifies whether static or dynamic link aggregation is used
- Ports: Here you can select the physical ports that should belong to a link aggregation group (a logical connection).

With the "Apply" button, the settings can be accepted and applied.

Dynamic (LACP)

This menu lets you decide whether LACP is executed dynamically, statically, or not at all.

The following settings are required for this:

• Type: Select whether LACP is to be executed dynamically, statically, or not at all.



- Group ID: This setting is relevant if you want to apply static link aggregation. Combine ports into one group for this by entering the same group ID. This setting will not be required for dynamic link aggregation.
- Mode: This setting is relevant for dynamic LACP. The LACP protocol is active for the port in active mode. The LACP protocol is only active for the port in passive mode if the remote station of the port connection is also in passive mode. The protocol is sent to bridge a link failure without packet loss. At least one side of the link must be configured as the active part with dynamic link aggregation.
- Port priority: This setting is relevant for dynamic LACP. If another port is required for a logical connection, the free dynamic port with the highest port priority is selected. The lower the number, the higher the priority.

3.9 Redundancy

This page provides an overview of the available redundancy protocols and their status. It is not possible to have multiple redundancy protocols running at the same time, so only one can be enabled. With the help of the edit buttons, you can access the protocols and carry out the configuration there.

The following protocols are available:

- MRP: The media redundancy protocol is a ring protocol for highly available networks, which is achieved by inserting redundant paths.
- RSTP: The rapid spanning tree protocol is a standardised method to manage mixed structures in the network and contains a mechanism for automatic reconfiguration.
- MSTP: MSTP generally can create a separate spanning tree for each VLAN.

The use of redundancy protocols guarantees your network increased reliability and availability in the event of a fault. The failure of a component is absorbed, and the subscribers not affected by the failure can continue to communicate.

3.9.1 **MRP**

The media redundancy protocol is a ring protocol for highly available networks. The high availability is made possible by redundant communication paths, which are set to shutdown state during normal operation. The subscribers connected in the network operate in a line topology, although it is physically a ring. In the event of a fault, communication can take place via the previously disabled path after a very short recovery time.

MRP uses a redundancy manager that tests the continuity of the ring by means of special test packets and reconfigures the network in the event of a fault and informs the subscribers accordingly. The guaranteed reconfiguration time, with up to 50 devices in the ring, is 200 ms. The reconfiguration time usually is less than 50 ms in a typical application.



Ring configuration

Please note that the ring must not be physically closed until MRP is fully configured. One device per ring must be configured as manager. The other devices must be configured as clients. The following settings are required for MRP:

- First ring port: Please select a port to work as primary ring port.
- Second ring port: Specify a second port to operate as a secondary ring port. Please note that the secondary ring port and the primary ring port must be different.
- This device operates as: Please specify whether the device should act as a manager or as a client. Please note that only one manager may be used per ring.

3.9.2 **RSTP**

The rapid spanning tree protocol (RSTP) is a standardised method for managing mixed structures, including a ring, on the network. It prevents network loops that can result from redundant transmission paths and includes a mechanism for automatic reconfiguration after a device or link failure.

Enable the RSTP function globally before configuring the corresponding parameters.

Root bridge information

The following parameters are displayed in this field:

- Root port: Indicates which port is working as the root port. This port is the shortest path to the root bridge
- Root bridge ID: Identification number of the current root bridge negotiated between the devices.
- Designated cost: Path cost calculated for the connection to the root bridge.
- Root bridge MAC address: Displays the MAC address of the root bridge.

Device settings

Configure the protocol for your application:

- Forward delay: The time a port waits before switching from the RSTP learning and listening state to the forwarding state. Enter a value between 4 and 30 seconds.
- Maximum age: The amount of time a bridge waits before attempting to reconfigure without receiving spanning tree configuration protocol messages. Enter a value between 6 and 40 seconds.



- Bridge priority: This value is used for negotiating the root bridge. The bridge with the lowest value has the highest priority and is chosen as the root bridge. The value must be between 0 and 61440 and a multiple of 4096.
- Hello Time: The time interval at which the switch sends BPDU (Bridge Protocol Data Unit) packets to check the current status of the RSTP. Enter a value between 1 and 10 seconds.
- TX hold count: Specifies the maximum number of Hello packets transmitted within an interval. A minimum of 1 and a maximum of 10 packets are allowed.

	😚 PROmesh P9+		Name of Station: PROmosh P94 Device Lectation: IP Address: 172.30.152.5 Logout Help
	Redundancy > RSTP		
帝 Home			
System Information Image: Diagnosis	Adjust the Rapid Spanning Tree Protocol (RSTP) settings here.	(m	3 Messages
			Delete messages
A Switching	On	Current Status 🗰 Inactive	Delete counter
Redundency	RSTP Configuration	*	
MRP RSTP	Geräte settings Port settings		PROmesh P9+
WSTP Configuration	Root Bridge Information		
Support 8 Contact	Root port 0 Designated Cost 0		~ : 이 아
	Root Bridge ID: 8000.50.61106.05F1:83 Root Bridge MAC-address:50.6106.05F1:83		
	RSTP Settings		
	Forward detay (s) Helio time (s)		
	Maximum age [6] TX hold count		
	20 ¢ 20 ¢		
	32,768		C. C. 1997
	Roset	Apply Cancel	
🖤 Language 🔨 🔨	@ 2022 Indu-Sol GmbH		

Figure 16: Device settings RSTP

Notice: Follow the rule to configure Forward Delay, Maximum Age and Hello Time:

2 * (Forward Delay Time - 1) >= MaxAge >= 2 * (Hello Time + 1).

Recommended procedure: Select a value for "Hello Time" and calculate with the formula 2 * (Hello Time + 1) in accordance with the rule given above to get the lower limit of the Maximum Age. Select a value for "Forward Delay Time" and use the formula 2 * (Forward Delay Time – 1) of the above rule to calculate the upper limit of the Maximum Age. Then select a Maximum Age between 6 and 40 seconds, which lies between the previously calculated limits.

When you have set the parameters, click "Apply" to apply the changes. The root bridge information is now displayed at the top of the page.



Port settings

Set the following port-related settings per port:

- Port: You can configure each ports individually.
- RSTP on: For each port, select whether or not to enable the Rapid Spanning Tree Protocol on that port.
- Status: Displays the current status of each port. The following are distinguished:
 - Blocking: Discards packets; does not learn addresses; receives and processes BPDUs
 - Listening: Discards packets; does not learn addresses; receives, processes, and transmits BPDUs
 - Learning: Discards packets; learns addresses; receives, processes, and transmits BPDUs
 - Forwarding: Forwards packets; learns addresses; receives, processes, and transmits BPDUs
 - Disabled: Discards packets; does not learn addresses; does not receive and process BPDUs
- Role: Each port can run in one of the following modes:
 - o Root port: A port in the forwarding state. Shortest way to the root bridge.
 - Designated port: A port in the forwarding state that allows communication to other bridges in the spanning tree.
 - Alternate port: An alternate path to the root bridge, in addition to the current root port.
 - Backup port: A backup path provided through a designated port towards the branches of the tree structure. Backup ports can only exist where two ports are connected as a loopback by a point-to-point connection or a bridge with two or more connections to a common LAN segment.
 - Disabled port: A port without any operational function in the tree structure.
- Priority: This allows the assignment of higher priorities to certain ports to influence the tree structure. Enter a number from 0 to 240. The value must be a multiple of 16.
- Costs: The cost from the sending bridge on the respective port of another bridge. Enter a number from 1 to 200,000,000. You can use this parameter to influence the structure of the tree.
 - \circ defined: The cost of a connection to the root bridge can be specified.
 - o designated: The designated costs are calculated by the RSTP and displayed here.
- Edge port: Specifies a port directly connected to an end device and not to another bridge (a switch). These ports cannot cause loops and therefore immediately switch to Forwarding mode. Changing the status of an edge port does not change the topology in any case. They speed up the reconfiguration time of the redundancy protocol by setting edge ports fixed.
 - Force: The port is configured as an edge port by default.
 - Auto: Edge ports are detected is automatically.



	📦 PR	PROmesh P9+										of Station: PROmesh P Location ress: 172 3 <u>0.152</u>	* 🗭 <u>adm</u> 5 Loop					
Ö Ü	Redundancy > RSTP																	
	-												_	4				
nation	Adjust	Adjust the Rapid Spanning Tree Protocol (RSTP) settings here.											-	3 Messages				
	On]									Currer	it Status 🛛 Inactiv	ve	Delete	messag e counte			
· · · · · ·	RSTP C	onfiguratio	on										^					
	Gerä	te settings	Port settings											PRO	nesh P9+			
nfiguration Contact	Port	RSTP on	Status	Role	Priority	C defined	ost designated	Edge force	port auto						i Ly i Ry			
	1		forwarding	disabled	128	20000	20000								iF			
	2		forwarding	disabled	128	20000	20000							P81	눈			
	4		forwarding	disabled	128	20000	20000							8				
	5		forwarding	disabled	128	20000	20000							P 25				
	6		forwarding	disabled	128	20000	20000											
	ž		forwarding	disabled	128	20000	20000							0	0000			
	8		forwarding	disabled	128	20000	20000							V-v-				
	9		forwarding	disabled	128	20000	20000											

Figure 17: Port settings

Click Apply to apply the settings after you have set the respective parameters.

3.9.3 **MSTP**

Instance configuration

You can create Multiple Spanning Tree instances in this menu. This permits creation of a separate spanning tree for each VLAN. The following settings are required for this:

- Instances ID: Select the Multiple Spanning Tree Instance ID here. This ID must be identical for all switches that are to belong to the same spanning tree.
- Priority: Each subscriber of an MST instance can be assigned a priority. The values can be assigned in steps of 4096 (starting with 4096). The lower the value, the higher the priority. The subscriber with the lowest priority is declared the spanning tree master.
- VLANs: You can specify a VLAN or a VLAN group for which the spanning tree is created here.

Port setting

This menu lets you make the following settings:

- MTSP on: Enable the settings made in this menu
- BPDU Guard: The BPDU Guard is a security mechanism of the STP and should be enabled on all access ports. If these ports receive a BPDU, they are disabled. This can prevent disruption of the network by manipulated BPDUs.
- Edge port: Specifies a port directly connected to an end device and not to another bridge (a switch). These ports cannot cause loops and therefore immediately switch to Forwarding mode. Changing the status of an edge port does not change the topology in any case. They speed up the reconfiguration time of the redundancy protocol by setting edge ports fixed.



- Enforcing: When enabled, the port is configured as an edge port by default.
- Auto: The port is not configured as an edge port by default.

3.10 System configuration

The system configuration page displays IP address settings, time settings, access options to the device, and general device information.

This page is to provide a concise view of the system configuration menu to help you understand how the device works and where action is needed.

You can switch directly to the corresponding protocols and functions in order to make the other settings there with the respective Edit button.

	🎲 PROmesh P9+			Name of Station: PROmesh P9+ Device Location: IP Address: 172:30.152.5 Logout He
	System Configuration			4
A Home				
System Information	Activated and deactivated swit	ch functions at a glance.	(Arm	12 Mercaner
			γ //	Delete messages
A Switching	Device Information	IP Configuration	Time Settings	Delete counter
 Redundancy 	Device name: PROmesh P9+	IP-Address: 172.30.152.5	System time: 11/30/2022, 7:52 PM	
A and a second second	Device location: -	Subnetmask 255.255.248.0	Uptime: 3 Hours	
System Configuration	Contact person: -	Gateway: 172.30.152.5	SNTP: X Inactive	PROmesh P9+
IP Configuration		DHCP: X Inactive		
Password				
Time Settings				
Access	SNMP	Access		
Backup				
Restore	SNMP: Active			
Firmware-Update		· · · · · · · · · · · · · · · · · · ·		
Reboot				
Support & Contact				and the second se

Figure 18: System configuration

3.10.1 **Device information**

The device information page allows you to assign a unique device name, installation location, and contact person to the device.

- Device name: This name corresponds to the PROFINET name and is assigned by means of DCP.
- Installation site: Specify the installation location of the device to facilitate localisation.
- Contact: Enter a contact person for the device.



The input fields are configured so that you may use up to 50 characters. Special characters may be used. The device name and installation location are displayed in the information bar at the top right and help you to keep track of the device.

3.10.2 **IP configuration**

The IP configuration can be performed either by the PROFINET controller, automatically using the Dynamic Host Configuration Protocol (DHCP) or manually. When the address is assigned automatically, the IP may change after a device restart, depending on the settings of the DHCP server.

PROFINET

If the device is configured in a PROFINET network, the device receives its IP configuration from the PROFINET controller. The IP configuration cannot be performed automatically or manually with an existing PROFINET connection.

Automatic

Select the checkbox "automatic (DHCP)" to get a configuration of the IP address, the subnet mask, and the default gateway from a server working in the network with corresponding function.

The device sends a request to the server and adopts the configuration received from the DHCP server after you have saved the settings by clicking on the Apply button. The device can no longer be reached via the default IP because now has a new IP address. Please contact your network administrator or use an appropriate tool (Indu-Sol ServiceTool) to obtain the new IP address.

Manual

If your network does not have a DHCP server or you want to make the settings manually, disable the "automatic (DHCP)" button and enter the following data:

- IP address: Please note that the IP address you set must be accessible from your PC so that you can connect to the device again to make the other settings.
- Subnet mask: Enter the subnet mask of the IP address, this separates the IP address into a network part and a device part. This defines which IP addresses can be reached directly by the device and which addresses must be addressed via a gateway.
- Gateway: Enter a default gateway. The gateway is used to communicate with devices outside your subnet.



Please check the settings carefully to avoid problems with duplicate IP addresses. The format of the IP address, the subnet mask and the gateway must be entered in decimal notation.

3.10.3 Password

On this page the default password for the users Admin and User can be changed. The usernames and rights of the administrator and the user are fixed and cannot be changed.

Form fields

- New password: Enter the password set for the previously selected user in this field. Please also note the information on assigning passwords in the section below.
- Confirm password: Repeat the password in this field to make sure that you have entered your password correctly.
- Current password: Please enter your current password here to ensure that you are authorised to change the password.

Notes on passwords

The security of your system is essentially related to the security of your passwords. Therefore, passwords generally should:

- not to use dictionary entries
- be as complex as possible
- use combinations of letters, numbers, and special characters
- use lower- and upper-case letters
- have at least eight characters
- never be written down

3.10.4 **Time setting**

In this menu you can store the device time of the switch. For this you can store the time:

- Automatically (SNTP)
- Manually

. Furthermore, the PROmesh P9+ can be used as a time server to provide other devices with the current system time.



	🍄 PROmesh P9+	Name of Station: PROmesh P9+ Device Location: IP Address: 172 30.192 5 Logout Heip
	System Configuration > Time Settings	
🔗 Home		
System Information Diagnosis	Here you can make adjustments to your time settings!	14 Messages
Switching	Settings ^	Delete messages Delete counter
Redundancy	System time: Wednesday, November 30, 2022 at 7:52 PM System uptime: 3 Hours 30 Minutes	
Configuration Device Information IP Configuration Password	Enable SNTP Server automatic (SNTP) manual 1190/0727 52 PM	PROmesh P9+
Time Settings SNMP Access Backup	Time zone (GMT+01:00) Europe/Berlin	
Restore Firmware-Update	Appy Carcer	
Factory Reset Reboot		Ref. usper
Support & Contact		

Figure 19: Time server

Automatically (SNTP)

- SNTP Server: Store the IP address of the time server. It is possible to store a second time server as redundancy.
- Update interval: You can determine the cycle in which the device time is synchronised with the time server here.
- Time zone: Then select your valid time zone

Manual

This setting lets you manually enter the current date and time by clicking the calendar icon. Furthermore, you can select your valid time zone under "Time zone".

3.10.5 **SNMP**

The Simple Network Management Protocol (SNMP) controls communication between the monitored devices and the monitoring station. It enables the reading and writing of system variables.

Current SNMP accesses

The overview table shows you the currently defined community strings and access permissions.

- Active: Indicates which community strings are currently enable and which are not.
- Community string: The accesses are defined by unique names that you can change.



- Read only: The community string allows read-only access.
- Read and write: The community string allows read and write access.
- Delete: You can mark the community strings to be deleted and then remove them with the "Delete" button.

Creating SNMP access

Click the "Add" button to create a new community string. The following parameters are required:

- Community string: Enter a unique name for the new SNMP access. A maximum of 32 characters is allowed.
- Access: Specify whether read-only or read and write access is allowed.

Save the settings by clicking on the "Create" button.

The device supports SNMP versions V1, V2C, and V3. Select the desired version.

The following additional settings are required for SNMP V3:

- Username: Assign a username here.
- Examination: Enter the authentication type here. You can choose between MD5 and SHA. Enter the corresponding password.
- Encryption: Select the encryption mechanism. You can choose between AES, DES, or no encryption.
- Access: Select whether only read, or read and write, permissions are granted by the configured access.

3.10.6 Access time

Settings

The time to automatic logout defines how long a session in web management remains without activity before an automatic logout occurs. You can set a time between 3 and 30 minutes. The default setting is 10 minutes.

Save your settings with the "Apply" button.

Furthermore, you can:

- Enable SSH and Telnet
- Enable web access via HTTP, HTTPS, or HTTP and HTTPS here



3.10.7 Backup

This menu item allows you to back the current configuration of the device up in a file. The backup can be saved as a download, to the SD card, or via TFTP.

The device creates and saves a backup file with all settings, which can be loaded at a later time using the Restore function.

- Download: The backup file will be stored in the browser's download directory, or the user can specify a path where the file is then saved.
- SD card: An SD card can be inserted into the SD card slot on the back of the device. This option then saves the backup file to this SD card.

3.10.8 Recovery

This menu item is used to import a previously saved backup file. The menu item Backup is used to create the backup file. The backup can be loaded via TFTP, as an upload or via SD card.

- Upload: The backup file is located on the computer currently in use and is transferred from there to the device.
- SD card: The backup file is stored on an SD card and is restored from there.

3.10.9 Firmware update

Here you can update the firmware of the device. Please only use firmware versions that you have received from Indu-Sol and that have been developed for the PROmesh switches.



	🍄 PROmesh P9+	Name of Station - PROmesh P9+ Device Location. IP Address; 172 30 152 5 Logout Help
	System Configuration > Firmware-Update	
🛞 Home		
System Information	Here you can choose an update method and execute it.	
Lini Diagnosis		16 Messages
ROFINET	Firmware Update	
Switching		Delete counter
Redundancy	File Upload SD-Card TFTP-Server	
System Configuration		
Device Information		C PROMESSI PSF
IP Configuration	Click here to select a file or Drag & Drop it into this box	
Password		
Time Settings		
SNMP	Start Firmware Up	date ps
Rockup		
Pactora		
Firmware-Update		
Factory Reset		
Reboot		
τ [@] m ⁰ Support & Contact		
🌒 Language 🔨	© 2022 Indu-Sol OmbH	

Figure 20: Firmware update

The firmware file is either provided by a TFTP server, uploaded to the device, or placed on an SD card. Before updating, check that you have selected the correct firmware image.

- Upload: The firmware update is located on the computer currently in use and is transferred from there to the device.
- SD card: The firmware update is stored on the SD card and installed from there.
- TFTP server: The firmware update is downloaded from a TFTP server on the network.

Preparation:

It is not recommended to perform the update if the MRP protocol is enabled. Please open the MRP ring first by pulling out one of the cables and then disable the media redundancy protocol. Now perform the firmware update.

Settings

- TFTP server IP address: Specify the IP address of the TFTP server available on the network in decimal dot notation.
- File name: Enter the name of the new firmware file to be installed here. Please specify the name relative to the root directory of the server.

Use the button "Start firmware update" to execute the action and confirm it in the window that opens. Please make sure that the firmware update can be executed completely.



Important:

Do not perform the following actions while the firmware update is in progress.

- Do not disconnect the device from the power supply voltage under any circumstances.
- Do not pull or change any network connectors.

A message will tell you when the update is complete. The device will restart automatically at that point.

3.10.10 **Factory settings**

This menu item is used to reset the device to its factory settings.

Click the "Reset to default" button for this and confirm it in the window that opens. The device must then be rebooted.

3.10.11 **Reboot**

You can restart the switch to perform a software reset here. Pressing the reboot button will exit the switch software and reboot the device.

You can also turn both power supply voltages of the switch off and on again to perform a hardware reset.

3.11 Support

The support section contains all relevant contact information for Indu-Sol

License information

The linked license.txt file contains information regarding the "Open Source Software" used.

3.12 Troubleshooting advice

- Check that the power supply is correct. At least one of the VDC LEDs must light up green.
- Check the link/act LEDs of the wired RJ45 sockets. The link LEDs must light up when a connection is established and flash when data is being transmitted.
- If in doubt, disconnect redundant network structures and reset the *PROmesh P9+* switch to factory settings. Make your settings again bit by bit and observe where the error occurs if the communication works afterwards.





4 Technical specifications

Network connections	9 x up to 1 G bit/s RJ45		
Power supply	12 V 48 V DC redundant power supply		
Power consumption	Maximum 8 W		
Dimensions (HxWxD)	110 mm x 60 mm x 131 mm		
Weight	0.9 kg		
Housing	Aluminium, anodised		
Storage temperature	-40 °C 75 °C		
Operating temperature	-40 °C 75 °C		
Humidity	Humidity 5% 95% RHD non-condensing		
Protection class	IP20 (not evaluated by UL)		
Assembly	35 mm DIN top-hat rail		
ЕМС	2014/30/EU EN 61000-6-2 / EN 55032		
LED display	Status LEDs / port LEDs / power supply		
Management	SNMP management		
management	Web interface management		
Switching technology	Store & Forward		
MAC address table	16 K MAC address table		
Ring	MRP		
	Spanning Tree		
	Port based VLAN		
	Tagged VLAN IEEE 802.1Q		
Class of service	IEEE802.1p Class of service with eight priority queues per		
	port		
Port mirror	RX packets only or TX and RX packets		
Firmware update	SD card, TFTP server, from local PC		
Bandwidth contr.	Incoming and outgoing		
DHCP client	DHCP client function to obtain an IP address from the DHCP		
	server		

Indu-Sol GmbH Blumenstraße 3 04626 Schmölln

Telefon: +49 (0) 34491 580-0 Telefax: +49 (0) 34491 580-499

info@indu-sol.com www.indu-sol.com

Wir sind zertifiziert nach DIN EN ISO 9001:2015